

## SPECIFIC MOUNTING INSTRUCTIONS FOR DIFFERENT VAN MODELS

### WARNINGS

*Make sure that you read the mounting instructions -included in the package- carefully.*

*The measures indicated in the following pages are recommended but not compulsory.*



**KEEP YOUR VAN SAFE.**

# INDEX

## CITROËN

Nemo (2007)	3
Berlingo (2016)	4
Jumpy (2017)	5
Jumper (2015)	6

## FIAT

Fiorino (2016)	3
Ducato (2017)	6
Talento (2017)	8
Doblò (2017)	10

## FORD

Transit connect (2013)	15
Transit courier (2014)	16
Transit custom (2012)	17
Transit T2 (2017)	18

## HYUNDAI

H350 (2015)	24
-------------	----

## IVECO

Daily (2014)	11
--------------	----

## MAN

TGE (3140)	25
------------	----

## MERCEDES

Citan (2012)	19
Vito (2014)	20
Sprinter (2006)	21

## NISSAN

NV-200 (2014)	22
E-NV-200 (2014)	23
NV-300 (2017)	8
NV-400 (2017)	9

## OPEL

Vivaro (2014)	8
Movano (2011)	9

## PEUGEOT

Bipper (2007)	3
Partner (2017)	4
Expert (2016)	5
Boxer (2015)	6

## RENAULT

Kangoo (2008)	7
Trafic (2014)	8
Master (2010)	9

## TOYOTA

Proace (2015)	5
---------------	---

## VOLKSWAGEN

Caddy (2015)	12
Transporter (2015)	13
Crafter (2017)	14

Distance from the door track  
to the central axis of the drill  
template

**MEASURE X = FLAT PART OF THE DOOR**

**If  $x < 12$  mm**

→ move the drill template **12-x mm**  
towards the fixed door.

**If  $x \geq 12$  mm**

→ Follow the standard  
mounting -refer to the drill template.

**BLACKSTONE**



PEUGEOT BIPPER




FIAT FIORINO



CITROËN NEMO

## INSTALLATION ON THE REAR DOOR




**! Place the drill template as shown in the picture.**

Distance from the bumper to the central axis of the drill template

**cm 71,4**

## INSTALLATION ON THE LATERAL DOOR



**! Place the drill template as shown in the picture.**

Distance from the door track to the central axis of the drill template

**cm 26,9**



**MEASURE X = FLAT PART OF THE DOOR**

**If  $x < 12$  mm**

→ move the drill template **12-x mm** towards the fixed door.

**If  $x \geq 12$  mm**

→ Follow the standard mounting -refer to the drill template.




PEUGEOT PARTNER



CITROËN BERLINGO

## INSTALLATION ON THE REAR DOOR




**! Place the drill template as shown in the picture.**

Distance from the bumper to the central axis of the drill template

**cm 72,4**

## INSTALLATION ON THE LATERAL DOOR



**! Place the drill template as shown in the picture.**

Distance from the door track to the central axis of the drill template

**cm 13,9**



**MEASURE X = FLAT PART OF THE DOOR**

**If  $x < 12$  mm**

→ move the drill template **12-x mm** towards the fixed door.

**If  $x \geq 12$  mm**

→ Follow the standard mounting -refer to the drill template.



PEUGEOT EXPERT




TOYOTA PROACE



CITROËN JUMPY

## INSTALLATION ON THE REAR DOOR




**! Place the drill template as shown in the picture.**

Distance from the bumper to the central axis of the drill template

**cm 101,9**

## INSTALLATION ON THE LATERAL DOOR



**! Place the drill template as shown in the picture.**

Distance from the door track to the central axis of the drill template

**cm 24**



**MEASURE X = FLAT PART OF THE DOOR**

**If  $x < 12$  mm**

→ move the drill template **12-x mm** towards the fixed door.

**If  $x \geq 12$  mm**

→ Follow the standard mounting -refer to the drill template.



PEUGEOT BOXER




CITROËN JUMPER



FIAT DUCATO

## INSTALLATION ON THE REAR DOOR




**! Place the drill template as shown in the picture.**

Distance from the bumper to the central axis of the drill template

**cm 99,4**

## INSTALLATION ON THE LATERAL DOOR



**! Place the drill template as shown in the picture.**

Distance from the door track to the central axis of the drill template

**cm 8,4**



**MEASURE X = FLAT PART OF THE DOOR**

**If  $x < 12$  mm**

→ move the drill template **12-x mm** towards the fixed door.


**If  $x \geq 12$  mm**

→ Follow the standard mounting -refer to the drill template.



RENAULT KANGOO

## INSTALLATION ON THE REAR DOOR




**! Place the drill template as shown in the picture.**

Distance from the bumper to the central axis of the drill template

**cm 75**

## INSTALLATION ON THE LATERAL DOOR



**! Place the drill template as shown in the picture.**

Distance from the door track to the central axis of the drill template

**cm 84**



**MEASURE X = FLAT PART OF THE DOOR**

**If  $x < 12$  mm**

→ move the drill template **12-x mm** towards the fixed door.

**If  $x \geq 12$  mm**

→ Follow the standard mounting -refer to the drill template.



RENAULT TRAFIC



FIAT TALENTO




OPEL VIVARO



NISSAN NV-300

## INSTALLATION ON THE REAR DOOR




! Place the drill template as shown in the picture.

Distance from the bumper to the central axis of the drill template

cm 84

## INSTALLATION ON THE LATERAL DOOR



! Place the drill template as shown in the picture.

Distance from the door track to the central axis of the drill template

cm 30



MEASURE X = FLAT PART OF THE DOOR

If  $x < 12 \text{ mm}$   
 → move the drill template  $12-x \text{ mm}$  towards the fixed door.

If  $x \geq 12 \text{ mm}$   
 → Follow the standard mounting -refer to the drill template.





RENAULT MASTER




NISSAN NV 400



OPEL MOVANO

## INSTALLATION ON THE REAR DOOR




**! Place the drill template as shown in the picture.**

Distance from the bumper to the central axis of the drill template

**cm 103**

## INSTALLATION ON THE LATERAL DOOR



**! Place the drill template as shown in the picture.**

Distance from the door track to the central axis of the drill template

**cm 20**



**MEASURE X = FLAT PART OF THE DOOR**

**If  $x < 12$  mm**

→ move the drill template **12-x mm** towards the fixed door.


**If  $x \geq 12$  mm**

→ Follow the standard mounting -refer to the drill template.



FIAT DOBLÒ

## INSTALLATION ON THE REAR DOOR




**! Place the drill template as shown in the picture.**

Distance from **the bumper** to the central axis of the drill template

**cm 70**

## INSTALLATION ON THE LATERAL DOOR



**! Place the drill template as shown in the picture.**

Distance from **the door track** to the central axis of the drill template

**cm 10**



**MEASURE X = FLAT PART OF THE DOOR**

**If  $x < 12$  mm**

→ move the drill template **12-x mm** towards the fixed door.


**If  $x \geq 12$  mm**

→ Follow the standard mounting -refer to the drill template.



IVECO DAILY

## INSTALLATION ON THE REAR DOOR




**! Place the drill template as shown in the picture.**

Distance from the bumper to the central axis of the drill template

**cm 110**

## INSTALLATION ON THE LATERAL DOOR



**! Place the drill template as shown in the picture.**

Distance from the door track to the central axis of the drill template

**cm 26**



**MEASURE X = FLAT PART OF THE DOOR**

**If  $x < 12$  mm**

→ move the drill template **12-x mm** towards the fixed door.


**If  $x \geq 12$  mm**

→ Follow the standard mounting -refer to the drill template.



VOLKSWAGEN CADDY

## INSTALLATION ON THE REAR DOOR




! Place the drill template as shown in the picture.

Distance from the bumper to the central axis of the drill template

cm 55,5

## INSTALLATION ON THE LATERAL DOOR



! Place the drill template as shown in the picture.

Distance from the door track to the central axis of the drill template

cm 39



MEASURE X = FLAT PART OF THE DOOR

If  $x < 12$  mm

→ move the drill template  $12-x$  mm towards the fixed door.


If  $x \geq 12$  mm

→ Follow the standard mounting -refer to the drill template.



VOLKSWAGEN TRANSPORTER

## INSTALLATION ON THE REAR DOOR




! Place the drill template as shown in the picture.

Distance from the bumper to the central axis of the drill template

cm 74

## INSTALLATION ON THE LATERAL DOOR



! Place the drill template as shown in the picture.

Distance from the door track to the central axis of the drill template

cm 30



MEASURE X = FLAT PART OF THE DOOR

If  $x < 12$  mm

→ move the drill template  $12-x$  mm towards the fixed door.


If  $x \geq 12$  mm

→ Follow the standard mounting -refer to the drill template.



VOLKSWAGEN CRAFTER

## INSTALLATION ON THE REAR DOOR




! Place the drill template as shown in the picture.

Distance from the bumper to the central axis of the drill template

cm 74

## INSTALLATION ON THE LATERAL DOOR



! Place the drill template as shown in the picture.

Distance from the door track to the central axis of the drill template

cm 30



MEASURE X = FLAT PART OF THE DOOR

If  $x < 12$  mm

→ move the drill template  $12-x$  mm towards the fixed door.


If  $x \geq 12$  mm

→ Follow the standard mounting -refer to the drill template.



FORD TRANSIT CONNECT

## INSTALLATION ON THE REAR DOOR




! Place the drill template as shown in the picture.

Distance from the bumper to the central axis of the drill template

cm 86

## INSTALLATION ON THE LATERAL DOOR



! Place the drill template as shown in the picture.

Distance from the door track to the central axis of the drill template

cm 26



MEASURE X = FLAT PART OF THE DOOR

If  $x < 12$  mm

→ move the drill template  $12-x$  mm towards the fixed door.


If  $x \geq 12$  mm

→ Follow the standard mounting - refer to the drill template.



FORD TRANSIT COURIER

## INSTALLATION ON THE REAR DOOR




! Place the drill template as shown in the picture.

Distance from the bumper to the central axis of the drill template

cm 84

## INSTALLATION ON THE LATERAL DOOR



! Place the drill template as shown in the picture.

Distance from the door track to the central axis of the drill template

cm 25,5



MEASURE X = FLAT PART OF THE DOOR

If  $x < 12 \text{ mm}$

→ move the drill template  $12-x \text{ mm}$  towards the fixed door.

If  $x \geq 12 \text{ mm}$


→ Follow the standard mounting -refer to the drill template.





FORD TRANSIT CUSTOM

## INSTALLATION ON THE REAR DOOR




! Place the drill template as shown in the picture.

Distance from the bumper to the central axis of the drill template

cm 98

## INSTALLATION ON THE LATERAL DOOR



! Place the drill template as shown in the picture.

Distance from the door track to the central axis of the drill template

cm 37



MEASURE X = FLAT PART OF THE DOOR

If  $x < 12 \text{ mm}$

→ move the drill template  $12-x \text{ mm}$  towards the fixed door.


If  $x \geq 12 \text{ mm}$

→ Follow the standard mounting -refer to the drill template.



FORD TRANSIT T2

## INSTALLATION ON THE REAR DOOR




! Place the drill template as shown in the picture.

Distance from the bumper to the central axis of the drill template

cm 105

## INSTALLATION ON THE LATERAL DOOR



! Place the drill template as shown in the picture.

Distance from the door track to the central axis of the drill template

cm 23



MEASURE X = FLAT PART OF THE DOOR

If  $x < 12$  mm

→ move the drill template  $12-x$  mm towards the fixed door.


If  $x \geq 12$  mm

→ Follow the standard mounting -refer to the drill template.



MERCEDES CITAN

## INSTALLATION ON THE REAR DOOR




! Place the drill template as shown in the picture.

Distance from the bumper to the central axis of the drill template

cm 75

## INSTALLATION ON THE LATERAL DOOR



! Place the drill template as shown in the picture.

Distance from the door track to the central axis of the drill template

cm 35,5



MEASURE X = FLAT PART OF THE DOOR

If  $x < 12 \text{ mm}$

→ move the drill template  $12-x \text{ mm}$  towards the fixed door.


If  $x \geq 12 \text{ mm}$

→ Follow the standard mounting -refer to the drill template.



MERCEDES VITO

## INSTALLATION ON THE REAR DOOR




! Place the drill template as shown in the picture.

Distance from the bumper to the central axis of the drill template

cm 87

## INSTALLATION ON THE LATERAL DOOR



! Place the drill template as shown in the picture.

Distance from the door track to the central axis of the drill template

cm 34



MEASURE X = FLAT PART OF THE DOOR

If  $x < 12$  mm

→ move the drill template  $12-x$  mm towards the fixed door.


If  $x \geq 12$  mm

→ Follow the standard mounting -refer to the drill template.



MERCEDES SPRINTER

## INSTALLATION ON THE REAR DOOR




! Place the drill template as shown in the picture.

Distance from the bumper to the central axis of the drill template

cm 106

## INSTALLATION ON THE LATERAL DOOR



! Place the drill template as shown in the picture.

Distance from the door track to the central axis of the drill template

cm 30



MEASURE X = FLAT PART OF THE DOOR

If  $x < 12$  mm

→ move the drill template  $12-x$  mm towards the fixed door.


If  $x \geq 12$  mm

→ Follow the standard mounting -refer to the drill template.



NISSAN NV 200

## INSTALLATION ON THE REAR DOOR




! Place the drill template as shown in the picture.

Distance from the bumper to the central axis of the drill template

cm 93

## INSTALLATION ON THE LATERAL DOOR



! Place the drill template as shown in the picture.

Distance from the door track to the central axis of the drill template

cm 49



MEASURE X = FLAT PART OF THE DOOR

If  $x < 12$  mm

→ move the drill template  $12-x$  mm towards the fixed door.


If  $x \geq 12$  mm

→ Follow the standard mounting -refer to the drill template.



NISSAN E-NV-200

## INSTALLATION ON THE REAR DOOR




**! Place the drill template as shown in the picture.**

Distance from the bumper to the central axis of the drill template

**cm 93**

## INSTALLATION ON THE LATERAL DOOR



**! Place the drill template as shown in the picture.**

Distance from the door track to the central axis of the drill template

**cm 49**



**MEASURE X = FLAT PART OF THE DOOR**

**If  $x < 12$  mm**

→ move the drill template **12-x mm** towards the fixed door.


**If  $x \geq 12$  mm**

→ Follow the standard mounting -refer to the drill template.



HYUNDAI H350

## INSTALLATION ON THE REAR DOOR




**! Place the drill template as shown in the picture.**

Distance from **the bumper** to the central axis of the drill template

**cm 101**

## INSTALLATION ON THE LATERAL DOOR



**! Place the drill template as shown in the picture.**

Distance from **the door track** to the central axis of the drill template

**cm 25**



**MEASURE X = FLAT PART OF THE DOOR**

**If  $x < 12$  mm**

→ move the drill template **12-x mm** towards the fixed door.

**If  $x \geq 12$  mm**


→ Follow the standard mounting -refer to the drill template.





MAN TGE

## INSTALLATION ON THE REAR DOOR




! Place the drill template as shown in the picture.

Distance from the bumper to the central axis of the drill template

cm 131,5

## INSTALLATION ON THE LATERAL DOOR



! Place the drill template as shown in the picture.

Distance from the door track to the central axis of the drill template

cm 30



MEASURE X = FLAT PART OF THE DOOR

If  $x < 12 \text{ mm}$

→ move the drill template  $12-x \text{ mm}$  towards the fixed door.

If  $x \geq 12 \text{ mm}$

→ Follow the standard mounting -refer to the drill template.